HOW TO



Control primary alarm panel from GTCOM2 ?

ARM/ DISARM methods:

- •Touch iButton keys to the reader
- •Send SMS to the module
- •Call to the module
- •ARM/ DISARM via mobile, web app

How to Control primary alarm panel from GTCOM2

Via iButton keys, short call, SMS, mobile, web app?



Prepare the module GTCOM2

- Insert SIM card
- Screw GSM antenna
- Connect iButton reader
- Connect the module to the primary panel
- Connect the module to the computer via mini USB

Attention!

• Disconnect power supply before wiring!

- The correct wiring procedure is as follows:
- Make sure power is turned off
- Make wiring connections to the terminals
- Apply power



The module can work with any central panel which has PSTN communicator and meets Ademco Contact ID data format according to SIA SIA DC-05 standard. Also Central panel must support phone number dialing using DTMF tones.

More information about GTCOM2 and primary alarm panel synchronization: https://www.topkodas.lt/downloads/

GTCOM2 user manual



Prepare SERA2 software

- Install SERA2 software (you will find it in https://www.topkodas.lt/)
- Help & Support > Downloads



Before You start, update firmware

System Options

- Outputs (PGM) Automation/Sensors

-Event Summary

Events Log.

^{i....} Firmware



Attention!

- If you want to edit existing configuration,
- You have to read it (press "Read" in the command line)
- Edit settings
- Write edited configuration (press "Write" in the command line)



Start iButton, phone number entering mode

- Go to SERA2> System Options> General System Options
- Set 1W (1- wire Bus) to Dallas 1- Wire Bus DS1990A/ DS18b20
- Press "Write" in the command line
- Press "Start iButton/RFID/ Phone programming mode" button

(a) SERA2 [GTCOM2]				-		×				
📄 File 🔌 Settings 🚗 Devices 🐺 Read [F5] 🛛 🞇 Write [F6] 👘 Update 🧐 Help										
System Options	System	· · · · ·								
- GSM Communications	General System Options System Fault/Troubles System Info									
Users/Access control	System Options		System Timers							
- Inputs/Burglar Alarm Zones	Object Name:	GTCOM2 4G DEMO	Test Time:	13:30 hh:mm		- 1				
- Outputs (PGM) - Automation/Sensors	SMS/APP Text Charset	Latin (160 SMS symbols)	Test Period:	1 Days	•	- 1				
Event Summary	SIM Card PIN:	****	Entry Delay	0 s		- 1				
- Events Log 	Installer Password:	****** (6 symbols)	Exit Delay:	0 s		- 1				
Firmware	SMS User Password:	****** (6 symbols)	Bell/Siren Cut-off Timer:	120 s						
	User Access Code Format:	4 - Digits 💌	Time Zone:	(GMT: + 2)	•					
	Keyswitch Zone Mode:	Level	Daylight saving time:							
	1W (1-Wire Bus)	Dallas 1-Wire Bus_DS1990A/DS18b20								
		Digital Input (Max. 3.3V!!!!)								
		Dallas 1-Wire Bus_DS1990A/DS18b20								
	Clear Events Bufer after reset	Aosong 1-Wire bus Humidity/Temperature Sensor	r DHT22/AM2301/AM2302/AM2305	5/AM2306/AM2320/AM2320B						
	Door Chime	V				- 1				
	Bell Squawk on ARM/DISARM					- 1				
aller.	Auto - reARM		Set Module Time from PC	Read Module Ti	me					
Pico and the second	Start iButton/RFID/Phone pro	gramming mode Stop programming	PC time: 2020	 0-08-06 08:11:14,Thurso	lay					
	Reset Device		Panel Time:							
10 - N	L		J							

- Go to SERA2> Users/ Access control window
- Touch iButton keys to the reader
- Go to System Options> General system Options
- Press "Stop programming " button

SERA2 [GTCOM2]												
📄 File 🔌 Settings 🔓 Devices 🐻 Read (F5) 🛛 🖓 Write (F6) 👘 Update 🧐 Help												
System Options Remote Control Users table												
GSM Communications Users Access Shedules Holidays												
PSTN CID to SMS Converter												
··· Users/Access control	ŀ	L ID	En		Liser Tel	iButton Code	REID Keycard	Keyh Code	ОЛТ		En	
- Outputs (PGM)	╟╴	001		Oser Name				******	NONE		Ë	2020.01
- Automation/Sensors	ľ	007		Master		0A0D00355013	0000000000		NONE		F	2020-0.
- Event Summary	I	002		User Name 2	+	0A0D00A56131	0000000000		NONE		F	2020-0.
Events Log	╟┝	003		User Name 3	+		000000000		NONE		H	2020-0.
RT Testing&Monitoring		004		User Name 4	+	UAUDUUBAE62D	000000000		NONE		H	2020-0
Firmware		005	<u> </u>	User Name 5	+	0A0D00925600	0000000000		NONE			2020-0:
		006		User Name 6	+	00000000000	0000000000		NONE			2020-0:
		007		User Name 7	+	00000000000	0000000000		NONE			2020-0:
		Loos		Heer Nome 8	±	00000000000	0000000000		NONE			2020-0

Start iButton/RFID/Phone programming mode

Stop programming

- Enter your phone number in the list
- Press "Write"

③ SERA2 [GTCOM2]												
📄 File 🔌 Settings 🔒 Dev	lices		Rea	d (F5) 🛛 🞇 Write (F6) 👘 Upa	late Help							
	Re	emote	Contr	ol Users table								
GSM Communications	U	sers	Acc	ess Shedules Holidays								- 1
PSTN CID to SMS Converter Users/Access control				<u> </u>						_		
- Inputs/Burglar Alarm Zones		D	En	User Name	User Tel.	iButton Code	RFID Keycard	Keyb Code	OUT	ARM/DISARM	En	
- Outputs (PGM)		001	<	Master	+37065558449	0A0D003B5615	0000000000	*****	NONE	V		2020-0
- Automation/Sensors		002	\checkmark	User Name 2	+	0A0D00A56131	000000000		NONE	V		2020-0
- Event Summary - Events Log		003	\checkmark	User Name 3	+	0A0D00A83607	0000000000		NONE	V		2020-0
- RT Testing&Monitoring		004	\checkmark	User Name 4	+	0A0D00BAE62D	000000000		NONE	V		2020-0
Firmware		005		User Name 5	+	0A0D00925600	000000000		NONE			2020-0
		006		User Name 6	+	000000000000	000000000		NONE			2020 ⁵ t
		007		User Name 7	+	00000000000	0000000000		NONE			2020-0

- Go to SERA2> Users/ Access Control window
- Modify list
- Press "Write" in the command line

Test the system

- Go to SERA2> RT Testing & Monitoring> Hardware
- Press "Start Monitoring" button
- Go to SERA2> RT Testing & Monitoring> Security Alarm Panel/ Access
- Touch iButton keys to the reader
- You will see the status of the system

③ SERA2 [GTCOM2]	
📄 File 🔌 Settings 🛛 🔒 Dev	rices 📱 Read (F5) 🛛 🖉 Write (F6) 👘 Update He
····· System Options	Monitoring window
GSM Communications PSTN CID to SMS Converter	Hardware Security Alarm Panel/Access Sensors/Automatio
Users/Access control	Start Monitoring Stop Monitoring
- Outputs (PGM)	GSM info
Event Summary	
	SIM card:
Firmware	Signal level:

SERA2 [GTCOM2] 🞇 Write [F6] 📄 File 🔌 Settings 🛛 🔒 Devices 🛛 👸 Read [F5] 🛑 Update 🛭 🔞 Help -Monitoring window- System Options - GSM Communications Hardware Security Alarm Panel/Access Sensors/Automation Event Monitoring - PSTN CID to SMS Converter -Inputs (ADC values)-Start Monitoring - Users/Access control Stop Monitoring IN1 10 0.10 V Inputs/Burglar Alarm Zones IN2 1231 11.78 V -GSM info-- Outputs (PGM) 863922030688072 IMEI: - Automation/Sensors 1/01 0.04 V 4 - Event Summary 0.05 V 8937002190800195358 1/02 5 SIM ICCID: Evente Log RT Testing&Monitoring : READY SIM card: ---- Firmware 28 Signal level: Registration:

- Go to SERA2> RT Testing & Monitoring> Security Alarm Panel/ Access
- You will see the real time status

③ SERA2 [GTCOM2]								
📄 File 🔌 Settings 🔝 Devices 🐺 Read [F5] 🛛 🞇 Write [F6] 🛑 Update 🧐 Help								
System Options	Monitoring window							
GSM Communications	Hardware Security Alarm Panel/Access Sensors/Automation Event Monitoring							
- Users/Access control		Security Alarm Panel Monitoring						
- Inputs/Burglar Alarm Zones	Alarm Alarm Shutdown Bypassed Forced	Outer Outer ADM						
···· Outputs (PGM)		System state Artivi						
Automation/Sensors	Alarm Alarm Shutdown Bypassed Forced	DISARM ARM SLEEP STAY						
- Event Summary	Tamper/Fault Tamper Shutdown							
RT Testing&Monitoring								
Firmware	Alarm Alarm Shutdown Dypassed Forced	System Voltage 🔽 OK						
	Tamper/Fault 🗾 Tamper Shutdown 📃	PTC Clock II OK						
	Zone4	Machda Baal Tina Chala						
	Alarm Alarm Shutdown Bypassed Forced							
	Tamper/Fault Tamper Shutdown	2020-08-06 08:37:43,1hursday						
SMART C		Access Control						
		iButton Read						
		Wiegand RFID Card/Key 000000000						



ARM/ DISARM with SMS messages

User phone number must be the SERA2> Users/ Access control list

ARM/ DISARM with SMS

USER – command from user commands list 123456 – user's password (default) Space character 030- command code Change security system's mode (ARM/DISARM/STAY/SLEEP Space character 1- ARM

Change security system's mode (ARM/DISARM/STAY/SLEEP)

030= command code (Change security system's mode (ARM/DISARM/STAY/SLEEP) ST = Security system mode 0-DISARM, 1-ARM, 2-STAY, 3-SLEEP



USER123456_030_ST

USER – command from user commands list 123456 – user's password (default) _ - Space character 030- command code _ - Space character ST - Configuration array

Change security system's mode (ARM/DISARM/STAY/SLEEP) 030= command code (Change security system's mode (ARM/DISARM/STAY/SLEEP) ST = Security system mode 0-DISARM, 1-ARM, 2-STAY, 3-SLEEP

Enter user phone number in the Sera2> Users/ Access control list

How to install Android app?

• Scan QR code





- Go to <u>https://www.topkodas.lt/seranova-app/</u>
- You will find information how to install App

How to add new system in app

- Default App Key: 123456
- Default User Access Code: 123456
- Go to SERA2> System Options> General System Options
- IMEI: Sera2> System options> System info





Control primary alarm panel from GTCOM2

Via iButton keys, short call, SMS, mobile, web app



Armed State (Level) Maintained Keyswitch ARM

Keyswitch ARM Armed State (Level)

More information about GTCOM2 and primary alarm panel synchronization: <u>https://www.topkodas.lt/downloads/</u>

More information via email:

info@topkodas.lt